

ACCESIA®



The Vet Dentistry Company

USER MANUAL

Accesia USB keyboard
Part 40056705

This keyboard is plug and play compatible with Windows PC's, no additional drivers needed. After plugging in the keyboard in a free USB port it may take a few minutes for the drivers to install.

The elastomer cover can be cleaned with hospital grade disinfectants including alcohol 80%. Before starting the cleaning process press the "key lock" button until the light goes on. After placing the keyboard in cleaning mode it can be cleaned and the activation of any key does not result in unwanted input. After pressing the "key lock" button again the keyboard will become active and ready for use.

Manufacturer declares that this product is in accordance with essential requirements and other relevant terms of the European regulation 2004/108/EC.

Doc. 40 ver.1.02